

### Installation Steps:

1

Lay the chains out on the ground making sure the chain is not twisted in any way. Ensure that the sharp, open-hook side of the chains are facing down, away from the tire. Double check that the chains are in the correct orientation (cross hooks facing down). If the hooks are facing up, tire damage may occur due to sharp open hooks contacting the tire.



2

Find the "gathering rings" and the 2 side chain fasteners on either side of the chain, on the other end, find "2 tails" located in the middle of the chain. Ensure the chains are in the correct orientation (Side hooks facing down, away from the tire). Drive over the chain and leave about 1 foot of chain clear from the tire.



3

Pull the chain from the side chain fasteners or the gathering rings up and over the tire as far as possible. On the inside of the tire, run the side chain fastener through the nearest side chain link, fold it back to itself and hook it on the connection link. After hooked, you will have several unused links beyond the fastener. Make note of the number of unused links.



4

Take 1 of the chain tails from the center of the chain and run it through the corresponding gathering rings and pull it tight. Pull the tail down toward the side chain on the corresponding side and attach with shackle.



### **Installation Steps:**

**5**

Do the same procedure on the other side and pull tight. At this point you may need to re-tighten your side chain fasteners to a new link on the side of the chain.



**6**

Slowly operate the vehicle for a short distance, step off, inspect that everything is correctly connected, and re-tighten the chains if necessary. Enjoy your new tire chains!